


## TECHNICAL CHARACTERISTICS

### INSTRUCTIONS FOR USE, MAINTENANCE INSTRUCTIONS



**MODELS 10, 10P, 10PZ, 10X, 10Y**

MANUALLY-OPERATED GAS VALVE  
WITH FLAME SURVEILLANCE DEVICE FOR COOKING APPLIANCES

 Gas Safety Certified		CE	
<b>AS 4624-2005</b>		<b>EN 126:2012 EN13611:2019 + AC:2021</b>	
models	<b>10, 10P, 10PZ, 10X, 10Y (SAI-400154)</b>	models	<b>10, 10X, 10Y, 10P, 10PZ (51CL4024)</b>

## GENERAL INSTRUCTIONS

Feature	Description
type	conical plug valve
applications	hot plates, ovens, grills etc
types of gas used	1 <sup>st</sup> – 2 <sup>nd</sup> – 3 <sup>rd</sup> family
group	1
number of outlets	1
nominal diameter	8
maximum working pressure	6.5 kPa
minimum working temperature	0°C
maximum working temperature	80/130°C
nominal flow rate (except inlet variants 15-16)	0.361 m <sup>3</sup> /h (test gas: air - pressure drop 125 Pa – AS 4624-2005) 0.323 m <sup>3</sup> /h (test gas: air - pressure drop 100 Pa – EN 126-2012)
Reduced flow rate (except inlet variants 15-16)	0.067 m <sup>3</sup> /h (test gas: air - pressure drop 125 Pa – AS 4624-2005) 0.060 m <sup>3</sup> /h (test gas: air - pressure drop 100 Pa – EN 126-2012)
nominal flow rate (inlet variants 15-16)	0.146 m <sup>3</sup> /h (test gas: air - pressure drop 125 Pa – AS 4624-2005) 0.130 m <sup>3</sup> /h (test gas: air - pressure drop 100 Pa – EN 126-2012)
Reduced flow rate (inlet variants 15-16)	0.045 m <sup>3</sup> /h (test gas: air – pressure drop 125 Pa – AS 4624-2005) 0.040 m <sup>3</sup> /h (test gas: air – pressure drop 100 Pa – EN 126-2012)
opening angle of max. flow rate	90°
opening angle of min. flow rate	160° (models 10; 10X) – 210° (models 10P; 10PZ)
external leak tightness	leakage ≤ 60 cc/h (1 ml/min) (air - pressure 15 kPa)
internal leak tightness	leakage ≤ 20 cc/h (0.3 ml/min) (air - pressure 15 kPa)
gas valve continued operation	40,000 cycles (EN 126:2012 - EN 13611:2019 + AC:2019) 10,000 cycles (AS 4624 – 2005)
Flame supervisor device continued operation	10,000 cycles (EN 126:2012 - EN 13611:2019 + AC:2019) 2,000 cycles (AS 4624 – 2005)
inlet gas connection	bracket, flange (see inlet variant table)
outlet gas connection	see outlet variant table
storage temperature range	-15°C to + 50°C
hold-on current/drop-out current (safety device)	≤ 180 mA / ≥ 60 mA (version 1) ≤ 110 mA / ≥ 20 mA (version 2) ≤ 60 mA / ≥ 10 mA (version 3)
Thermocouples maximum closing time	90 sec

These valves can be used with pipes of various diameters and flat manifolds.

To ensure a perfect seal, place an elastomer gasket between the manifold and the valve.

Gaskets of different materials can be used for the manifold depending on the temperature reached: silicon elastomer gaskets are resistant up to 130°C (all colors except black) while nitrile elastomer gaskets are resistant up to 80°C (black gasket).

## INSTRUCTIONS FOR USE

To turn the valve on, simultaneously press and turn the control shaft.

Holding down the control shaft and turning it anti-clockwise allows the gas to pass to the burner.

A few seconds after the burner ignites, the thermocouple generates enough current to hold the safety magnet open. The control shaft needs no longer be pressed down.

When it's indicated on the assembly drawing the ignition of the valve can only be done with the spindle in 90°A position.

Maximum flow-rate is reached after turning the control shaft through 90°; reduced flow-rate is reached by continuing the rotation up to 160° except model 10Y (210° for model 10P and PZ).

The gas valve can be equipped with one or more microswitches, which can be firmly fastened by means of a metal staff. The microswitches are activated by simply pushing the spindle inward or by rotation of the spindle – see table 1.

As regards the gas valve model 10, X variant (cap marked X), the control shaft can be also turned 90° clockwise, without any passing of gas, to operate one or more microswitches.

As regards the gas valve model 10, Y variant (cap marked Y), the maximum rotation is 90° anti-clockwise, in this position the maximum flow-rate is reached.

If the flame should accidentally go out, the thermocouple cools and the current is reduced, the safety magnet is closed and the flow of gas is blocked after a few seconds.

The valve has an adjustable perforated metering screw (by-pass) which fixes the reduced flow-rate at a preset value when fully tightened. If a different type of gas is used, the amount of reduced flow can be adjusted by turning the by-pass beside the cap with a screwdriver.

TABLE 1 - MICROSWITCH CHARACTERISTICS

Nominal tension	250 V
Method for operation	push-button
Max. operating temperature	125 °C
Contact distance	small – standard
Protection level	IP00
Insulation class	I
Pollution situation	standard
Heat-resistance	category D
Tracking index	PTI250

### ASSEMBLY INSTRUCTIONS

**The valves are designed to be used inside the cooking appliances, protected from any possible infiltrations of liquid or dirt and from the atmospheric agents. The non-observance of this prescription can compromise the correct working and the safety of the product.**

The valves are designed to be used with manifolds of different diameters using flange or bracket fastenings.

To ensure a perfect seal, place an elastomer gasket between the ramp and the valve.

The outlet is designed for an injector or connection pipe to the burner.

To avoid damage that may compromise correct functioning of the valve, do not exceed the tightening torques listed in the attached tables.

**To avoid dirt or other material entering the equipment which may affect functioning of the valve, a suitable filter should be mounted on the manifold supply inlet.**

### MAINTENANCE INSTRUCTIONS

Maintenance of the taps is not foreseen, in case of failure or incorrect operation replace the tap with a new one (same model and same characteristics).

**NB.: Leak test should be performed using a suitable appliance. Leak test mustn't be done by means of a flame or immersion of the valve in water or other liquids. The non-observance of this prescription can compromise the correct working and the safety of the product.**

**VARIANTS**
**INLET VARIANTS**

inlet	denomination		assembly	
1 – 1N	single bracket	1 screw	tube diameter 14 mm	(hole diameter 8.2 mm)
2 – 2N	single bracket	1 screw	tube diameter 16 mm	(hole diameter 8.2 mm)
5 – 5N	single bracket	1 screw	tube diameter 18 mm	(hole diameter 8.2 mm)
8 – 8N	bracket	2 screws	tube diameter 18 mm	(hole diameter 8.2 mm)
9 – 9N	bracket	2 screws	tube diameter 1/2" gas	(hole diameter 8.2 mm)
13 – 13N	bracket	2 screws	tube diameter 16 mm	(hole diameter 8.2 mm)
14	flange	2 screws	flat tube	(hole diameter 5.7 mm)
15 – 15N	bracket	2 screws	tube diameter 8 mm	(hole diameter 5.7 mm)
16 – 16N	bracket	2 screws	tube diameter 10 mm	(hole diameter 5.7 mm)
17 – 17N	bracket	2 screws	tube diameter 14 mm	(hole diameter 8.2 mm)
19 – 19N	bracket	2 screws	tube diameter 19 mm	(hole diameter 8.2 mm)
20 – 20N	bracket	2 screws	tube diameter 17 mm	(hole diameter 8.2 mm)
27 – 27N	single bracket	1 screw	tube diameter 16 mm	(hole diameter 8.2 mm)

**OUTLET VARIANTS**

outlet	denomination	assembly
A	injector	injector + external thread
B	injector	injector
C	tube diameter 8 mm	compression fitting
D	tube diameter 6 mm	compression fitting
E	G 1/4"	flared tube
F	M 140 x 1.5	flared tube
G	tube diameter 7 mm	compression fitting
H	M 16 x 1.5	flared tube
I	tube diameter 6 mm	compression fitting
K	tube diameter 4 mm	compression fitting
J	injector	injector
L	tube diameter 7 mm	compression fitting
M	tube diameter 8 mm	compression fitting
N	tube diameter 10 mm	compression fitting
O	tube diameter 6.35 mm	compression fitting
P	tube diameter 6 mm	compression fitting
Q	tube diameter 6.35 mm	compression fitting
R	injector	injector
S	tube diameter 6 mm	compression fitting
T	tube diameter 8 mm	compression fitting
U	tube diameter 8 mm	compression fitting
V	G 1/8"	various
W	M 16 x 1.25	flared tube
Y	tube diameter 7 mm	compression fitting
X	Gc 1/8" angle 6°	various
Z	tube diameter 8 mm	compression fitting

**Max. torque values:**

maximum torque value		
<i><b>Component</b></i>	<b>Nm</b>	<b>lbf.in</b>
Nut + (olive) + tube for outlet of valves	15	133
Screws for fixing brackets	1.5	13
Injectors	4	35

**MANUFACTURING DATE CODES**

MONTH	CODE
JANUARY	N
FEBRUARY	O
MARCH	P
APRIL	R
MAY	S
JUNE	T
JULY	U
AUGUST	V
SEPTEMBER	W
OCTOBER	X
NOVEMBER	Y
DECEMBER	Z

YEAR	CODE
2020	0
2021	1
2022	2
2023	3
2024	4
2025	5
2026	6
2027	7
2028	8
2029	9

EXAMPLE: A COMPONENT PRODUCED IN APRIL 2023 IS MARKED

**R3**

Alternatively, on the component can be marked a four digit code indicating the week (first two digits) and the year of production (last two digits).

EXAMPLE: A COMPONENT PRODUCED THE 14<sup>TH</sup> WEEK OF 2023 IS MARKED

**1423**

Alternatively, on the component can be marked the day (first digits), the month (according with the code in table above) and the year of production (last two digits).

EXAMPLE: A COMPONENT PRODUCED IN APRIL, 19 2023 IS MARKED

**19 R 23**

Alternatively, on the component can be laser marked a six digit code indicating the machine (first and second digit), week (third and fourth digit), and the year of production (last two digits).

