

## TECHNICAL CHARACTERISTICS

### INSTRUCTIONS FOR USE, MAINTENANCE INSTRUCTIONS



#### MODELS 14

MANUALLY-OPERATED GAS VALVE  
WITH FLAME SURVEILLANCE DEVICE FOR COOKING APPLIANCES

		<h1>CE</h1>	
		<b>EN 437:2003 + A1:2009</b> <b>EN 126:2012</b> <b>EN 13611:2007+A1:2011</b>	
		models	<b>14 (51BU3852)</b>

## GENERAL INSTRUCTIONS

Feature	Description
type	conical plug valve
applications	hot plates, ovens, grills etc
types of gas used	1 <sup>st</sup> – 2 <sup>nd</sup> – 3 <sup>rd</sup> family
group	1
number of outlets	1
nominal diameter	8
maximum working pressure	6.5 kPa
minimum working temperature	0°C
maximum working temperature	80/130°C
nominal flow rate	0.27 m <sup>3</sup> /h (test gas: air - pressure drop 100 Pa – EN 126-2012)
Reduced flow rate	0.060 m <sup>3</sup> /h (test gas: air - pressure drop 100 Pa – EN 126-2012)
opening angle of max. flow rate	90°
opening angle of min. flow rate	160°
external leak tightness	leakage ≤ 60 cc/h (1 ml/min) (air - pressure 15 kPa)
internal leak tightness	leakage ≤ 20 cc/h (0.3 ml/min) (air - pressure 15 kPa)
gas valve continued operation	40,000 cycles (EN 126:2012 - EN 13611:2007 + A2:2011)
Flame supervisor device continued operation	10,000 cycles (EN 126:2012 - EN 13611:2007 + A2:2011)
inlet gas connection	bracket, flange (see inlet variant table)
outlet gas connection	see outlet variant table
storage temperature range	-15°C to + 50°C
hold-on current/drop-out current (safety device)	≤ 180 mA / ≥ 60 mA (version 1) ≤ 110 mA / ≥ 20 mA (version 2) ≤ 60 mA / ≥ 10 mA (version 3)
Thermocouples maximum closing time	90 sec

These valves can be used with pipes of various diameters and flat manifolds.

To ensure a perfect seal, place an elastomer gasket between the manifold and the valve.

Gaskets of different materials can be used for the manifold depending on the temperature reached: silicon elastomer gaskets are resistant up to 130°C (all colors except black) while nitrile elastomer gaskets are resistant up to 80°C (black gasket).

## INSTRUCTIONS FOR USE

To turn the valve on, simultaneously press and turn the control shaft.

Holding down the control shaft and turning it anti-clockwise allows the gas to pass to the burner.

A few seconds after the burner ignites, the thermocouple generates enough current to hold the safety magnet open. The control shaft needs no longer be pressed down.

Maximum flow-rate is reached after turning the control shaft through 90°; reduced flow-rate is reached by continuing the rotation up to 160°.

If the flame should accidentally go out, the thermocouple cools and the current is reduced, the safety magnet is closed and the flow of gas is blocked after a few seconds.

The valve has an adjustable perforated metering screw (by-pass) which fixes the reduced flow-rate at a preset value when fully tightened. If a different type of gas is used, the amount of reduced flow can be adjusted by turning the by-pass beside the cap with a screwdriver.

### ASSEMBLY INSTRUCTIONS

**The valves are designed to be used inside the cooking appliances, protected from any possible infiltrations of liquid or dirt and from the atmospheric agents. The non-observance of this prescription can compromise the correct working and the safety of the product.**

The valves are designed to be used with manifolds of different diameters using flange or bracket fastenings.

To ensure a perfect seal, place an elastomer gasket between the ramp and the valve.

The outlet is designed for an injector or connection pipe to the burner.

To avoid damage that may compromise correct functioning of the valve, do not exceed the tightening torques listed in the attached tables.

**To avoid dirt or other material entering the equipment which may affect functioning of the valve, a suitable filter should be mounted on the manifold supply inlet.**

### MAINTENANCE INSTRUCTIONS

Maintenance of the taps is not foreseen, in case of failure or incorrect operation replace the tap with a new one (same model and same characteristics).

**NB.: Leak test should be performed using a suitable appliance. Leak test mustn't be done by means of a flame or immersion of the valve in water or other liquids. The non-observance of this prescription can compromise the correct working and the safety of the product.**

**VARIANTS**
**INLET VARIANTS**

inlet	denomination		assembly	
1 – 1N	single bracket	1 screw	tube diameter 14 mm	(hole diameter 8.2 mm)
2 – 2N	single bracket	1 screw	tube diameter 16 mm	(hole diameter 8.2 mm)
5 – 5N	single bracket	1 screw	tube diameter 18 mm	(hole diameter 8.2 mm)
8 – 8N	bracket	2 screws	tube diameter 18 mm	(hole diameter 8.2 mm)
9 – 9N	bracket	2 screws	tube diameter 1/2" gas	(hole diameter 8.2 mm)
13 – 13N	bracket	2 screws	tube diameter 16 mm	(hole diameter 8.2 mm)
14	flange	2 screws	flat tube	(hole diameter 5.7 mm)
15 – 15N	bracket	2 screws	tube diameter 8 mm	(hole diameter 5.7 mm)
16 – 16N	bracket	2 screws	tube diameter 10 mm	(hole diameter 5.7 mm)
17 – 17N	bracket	2 screws	tube diameter 14 mm	(hole diameter 8.2 mm)
19 – 19N	bracket	2 screws	tube diameter 19 mm	(hole diameter 8.2 mm)
20 – 20N	bracket	2 screws	tube diameter 17 mm	(hole diameter 8.2 mm)
27 – 27N	single bracket	1 screw	tube diameter 16 mm	(hole diameter 8.2 mm)

**OUTLET VARIANTS**

outlet	denomination	assembly
A	injector	injector

**Max. torque values:**

maximum torque value		
Component	Nm	lbf.in
Screws for fixing brackets	1.5	13
Injectors	4	35

**MANUFACTURING DATE CODES**

MONTH	CODE
JANUARY	N
FEBRUARY	O
MARCH	P
APRIL	R
MAY	S
JUNE	T
JULY	U
AUGUST	V
SEPTEMBER	W
OCTOBER	X
NOVEMBER	Y
DECEMBER	Z

YEAR	CODE
1992	A
1993	B
1994	C
1995	D
1996	E
1997	F
1998	H
1999	I
2000	J
2001	K
2002	L
2003	M
2004	4
2005	5
2006	6
2007	7
2008	8
2009	9
2010	0
2011	1
2012	2
2013	3
2014	4
2015	5
2016	6

EXAMPLE: A COMPONENT PRODUCED IN APRIL 2004 IS MARKED

**R4**

Alternatively, on the component can be marked a five digit code indicating the day (first two digits), the month (third digit – according with the code in table above) and the year of production (last two digits).

EXAMPLE: A COMPONENT PRODUCED IN APRIL, 19 2004 IS MARKED

**19 R 04**

Alternatively, on the component can be marked a four digit code indicating the week (first two digits) and the year of production (last two digits).

EXAMPLE: A COMPONENT PRODUCED THE 14<sup>TH</sup> WEEK OF 2004 IS MARKED

**1404**